

Installation Instructions for KPMI Part No: <u>96-96000</u> KTM (Motorcycles) • All RFS Engines 400cc thru 560cc • 2000-'09 KTM (ATV) • All RFS Engines 450cc thru 525cc • 2008-'09 Lightweight Racing Valve Spring Kit

When installing KPMI Lightweight Racing Spring Kits it is important to maintain these highly stressed components in accordance with factory service limits. Always consult with qualified professionals suited to inspect your machine.

A) 96-96000 Kit Includes

<u>Qty</u>	Application	Description
2 - Pcs	Intake	Titanium Retainers
2 - Pcs	Exhaust	Titanium Retainers
2 - Prs	Intake	Chrome Silicon Springs
2 - Prs	Exhaust	Chrome Silicon Springs
2 - Pcs	Intake	H.T. Steel Basewasher
2 - Pcs	Exhaust	H.T. Steel Basewasher
2 - Pcs	Intake	Spring Shims
2 - Pcs	Exhaust	Spring Shims

*For some RFS engines it may be necessary to utilize the 96-96035 and 96-96039 spring shims included in this kit to achieve the listed installation height.

B) Recommended Installed Height - Intake/Exhaust

1.	Installed Height	1.170"-1.180"
2.	Seat Pressure	75 #
3.	Open Pressure at 0.395" valve lift	201 #
4.	Open Pressure at 0.435" valve lift	214 #
5.	Max Valve Lift**	0.435"

**Cams with greater than stock lift may require the use of shortened seals KPMI part number (71029-4). Always check clearances.

C) Notes

1. The difference between the installed height and the coil bind height is considered "Free-Travel"


The coil bind height is determined by compressing the spring or springs with the retainer and basewasher in place, a vice can be used for this operation, once springs are compressed measure the distance between the retainer and basewasher where the outer spring contacts them.

- 2. Free-travel should always be gross valve lift +.060" for safe operation.
- 3. Retainer to seal and retainer to guide clearance should also be gross valve lift +.060" for safe operation.
- 4. Failure to check valve train clearances can result in serious damage to an engine

Packaged By:_


Date:____

TECH TIPS



Valve Train Terminology

- 1. Stem Protrusion is measured from the tip of the valve stem to the cylinder head. See Figure 1.
- 2. Outer spring installed height is measured where the outer spring contacts the retainer and lower component when assembled. See Figure 1.
- 3. Inner spring installed height is measured where the inner spring contacts the retainer and lower component when assembled. See Figure 1.
- 4. Retainer to guide clearance is the distance between the valve guide (w/o the seal) and the bottom of the retainer, with the valve in the closed position. See Figure 1 and Notes 3 & 4.
- 5. Retainer to seal clearance is the distance between the valve stem seal and the bottom of the retainer, with the valve in the closed position. See Figure 1and Notes 3 & 4.



Installed Height

1. In Figure 2 the installed height is measured from where the outer spring contacts the retainer and the basewasher. This measurement is taken when the valve, basewasher, retainer, and keepers are assembled in the cylinder head.

Coil Bind / Solid Height:

1. In Figure 3 the coil bind height is determined by compressing the spring or springs with the retainer and basewasher in place, a vice can be used for this operation, once springs are compressed measure the distance between the retainer and basewasher where the outer spring contacts them.

Notes:

- 1. The difference between the installed height and the coil bind height is considered "Free-Travel"
- 2. Free-travel should always be gross valve lift +.060" for safe operation.
- 3. Retainer to seal and retainer to guide clearance should also be gross valve lift +.060" for safe operation.
- 4. Failure to check valve train clearances can result in serious damage to an engine.