



Installation Instructions for KPMI Part No: **82-86070**

Polaris • Various 4-Cylinders • 2020-'23

Lightweight Racing Valve Spring Kit

Slingshot 2020-2023 / RZR Pro R 2022-2023

Being at the forefront of valvetrain development in the side by side market, KPMI® takes pride in being able to development spring kits for the top engine builders around the world. Because of this fact, KPMI® processes valued feedback when offering new designs or modifying existing. Pay close attention to the pressures and retainer material offered. KPMI® recommends heat-treated-steel-retainers for all endurance applications and leaves it up to the most experience engine builder to select titanium retainers when mass reduction is imperative and normal maintenance teardowns are routine after each race. As an additional note, our race customers are using less open pressure for the Turbo's and only using the Beehive and higher open pressure with experience and knowledge of the treatment of mating parts, clearances and oils. Matching a spring design to given valvetrain mass and cam dynamics is a science and when in doubt you must confer with an experienced builder.

A) 82-86070 Kit Includes

<u>Description</u>	<u>Qty</u>	<u>Application</u>
H.T. Steel Retainers	16 - Pcs	Intake / Exhaust
Chrome Silicon Springs	16 - Pcs	Intake / Exhaust
Tophat Seal	16 - Pcs	Intake / Exhaust

Notes: This spring kit is also designed for compatibility with the OEM integrated Seal/Base (OE# 3610212)

B) Recommended Installed Height - Intake/Exhaust

1. Installed Height	1.355" - 1.365"
2. Seat Pressure	80 #
3. Open Pressure at 0.360" Lift	183 #
4. Open Pressure at 0.435" Lift	205 #
5. Max Valve Lift	0.435"

C) Notes

- The difference between the installed height and the coil bind height is considered "Free-Travel"

The coil bind height is determined by compressing the spring or springs with the retainer and basewasher in place, a vice can be used for this operation, once springs are compressed measure the distance between the retainer and basewasher where the outer spring contacts them.

- Free-travel should always be gross valve lift +.060" for safe operation.
- Retainer to seal and retainer to guide clearance should also be gross valve lift +.060" for safe operation.
- Failure to check valve train clearances can result in serious damage to an engine

Packaged By: _____

Date: _____

TECH TIPS




Figure 1

Valve Train Terminology

1. Stem Protrusion is measured from the tip of the valve stem to the cylinder head. See Figure 1.
2. Outer spring installed height is measured where the outer spring contacts the retainer and lower component when assembled. See Figure 1.
3. Inner spring installed height is measured where the inner spring contacts the retainer and lower component when assembled. See Figure 1.
4. Retainer to guide clearance is the distance between the valve guide (w/o the seal) and the bottom of the retainer, with the valve in the closed position. See Figure 1 and Notes 3 & 4.
5. Retainer to seal clearance is the distance between the valve stem seal and the bottom of the retainer, with the valve in the closed position. See Figure 1 and Notes 3 & 4.




Figure 2

Figure 3

Installed Height

1. In Figure 2 the installed height is measured from where the outer spring contacts the retainer and the basewasher. This measurement is taken when the valve, basewasher, retainer, and keepers are assembled in the cylinder head.

Coil Bind / Solid Height:

1. In Figure 3 the coil bind height is determined by compressing the spring or springs with the retainer and basewasher in place, a vice can be used for this operation, once springs are compressed measure the distance between the retainer and basewasher where the outer spring contacts them.

Notes:

1. The difference between the installed height and the coil bind height is considered "Free-Travel"
2. Free-travel should always be gross valve lift +.060" for safe operation.
3. Retainer to seal and retainer to guide clearance should also be gross valve lift +.060" for safe operation.
4. Failure to check valve train clearances can result in serious damage to an engine.